

# Assembly Instruction



4100021 CABINET JOVE

### STEP1



### STEP2



A:2PCS



B:4PCS



C:8PCS



D:2PCS

### STEP3



### STEP4



E: 12PCS



F: 12PCS



G:1PC