

# EBB & FLOW

## Technical information

Pillar Table Lamp  
Ø19

IP20  
E27, max 25W

---

This lamp must be fitted and installed by a qualified electrician to avoid hazard.


In some countries, electrical installation work may only be carried out by an authorised electrical contractor.

Contact your local electricity authority for advice.

If the external flexible cord is damaged, it shall be exclusively replaced by the manufacturer.

The main voltage written in the technical information shall not be exceeded.

For any questions about your EBB & FLOW product, please contact your local dealer or [info@ebbandflow.dk](mailto:info@ebbandflow.dk).



# EBB & FLOW

## Technical information

Pillar Table Lamp  
Ø19

IP20  
E27, max 25W

---

This lamp must be fitted and installed by a qualified electrician to avoid hazard.

In some countries, electrical installation work may only be carried out by an authorised electrical contractor.

Contact your local electricity authority for advice.

If the external flexible cord is damaged, it shall be exclusively replaced by the manufacturer.

The main voltage written in the technical information shall not be exceeded.

For any questions about your EBB & FLOW product, please contact your local dealer or [info@ebbandflow.dk](mailto:info@ebbandflow.dk).

