



CLEANING AND MAINTENANCE

HOW TO EXTRACT AND CLEAN THE AERATORS


Hidden aerator

ALL COLLECTIONS




Waterfall aerator

PREMIER




Curtain aerator

AXIS

Please contact sat@grb.es to order the required key.

CLEANING AND MAINTENANCE

HOW TO EXTRACT AND CLEAN THE THERMOSTATIC FILTERS




50% Vinagre
Vinegar · Vinaigre

50% Agua
Water · Eau


Wall thermostatics

ALL COLLECTIONS




Built-in thermostatics

ALL COLLECTIONS



Built-in thermostatics


INCOOL




CLEANING AND MAINTENANCE

HOW TO CHANGE THE CARTRIDGE

Mixer cartridge



Thermostatic cartridge




CLEANING AND MAINTENANCE

HOW TO CLEAN SURFACES AND COATINGS


Cleaning tips for GRB products:

- Use **soft and clean** cloths.
- **Avoid abrasive products**
- **Do not use** cleaning products that contains **hydrochloric acid, formic acid, chlorine bleach or acetic acid**
- **Avoid mixing** cleaning products.
- **Do not apply the cleaning product** directly on the faucet, apply it to a soft cloth.
- After the cleaning process, **rinse the GRB products with clean water**, removing any cleaning products used, and dry the products with a soft cloth.



CLEANING AND MAINTENANCE

HOW TO CLEAN SHOWERHEADS AND HAND-SHOWERS



Periodically, rub the outlet diffusers distributed by the spray head or shower handle with your hand **retirar la suciedad** o los restos de minerales que puedan quedar secos obstruyendo los orificios de salida.

After daily **use of the sprinklers**, it is **recommended to empty the water accumulated** on the internal outlet surface, to avoid blockages or lime buildup in the outlet holes.



Premier



Tender



Eco-Prime



Ten Pro



Showerheads



Handshowers & hoses



Bars & Supports



Kits



Jets & Spouts



Valves



Accessories



Collectivities



GRB
Solutions